



INSTALLATION

READ THESE INSTRUCTIONS BEFORE YOU BEGIN INSTALLATION

Snap track provided with the ACT interface is to be mounted on the 2-1/2" piece of 1" wide double face tape in the base of the enclosure. Determine exactly where the snap track should be located in order to accommodate gauge, wiring, etc. Clean the bottom surface of the snap track, remove the protective material from the tape, and carefully press the snap track into position on the tape in the base of the enclosure.

If circuit board slides out of snap track, install the round foam nonconductive "stop" provided to the top side of the snap track. Pressure of foam stop (Part # HW017) against bottom of interface will hold in place. Remove protective paper from foam stop and press sticky surface to top side of snap track. Snap interface back into place in snap track.

Use only fingers to remove board from snap track. Slide out of snap track or push out against side of snap track and lift that side of the circuit board to remove. Do not flex board or use tools.

POWER CONNECTIONS

Be sure to follow all local and electrical codes when installing conduit or other mechanical fasteners to enclosure, and in wiring of power and signal.

CHECKOUT

After all power and signal wiring connections have been made and checked, place cover on enclosure base and fasten securely using the two #6 slotted hex-head self-tapping screws provided.